







## INSTALLATION INSTRUCTION

### PART LIST

1 x1	2 x2	3 x4	4 x4
			



**GB**

- Check the manual.
- Maximum total load - 150 kg.
- Do not use the bumper, unless your health condition allows it. Certain illnesses and medications, as well as the effects of alcohol and drugs, can pose risks during use.
- Do not use the bumper in unfavorable weather conditions, eg in strong wind.
- Warning, electrical hazard. Identify all electrical hazards in the work area, e.g. overhead power lines or other hazardous electrical equipment, and do not use the bumper when there is a risk of electric shock.